



## Product Recall – page 1 of 2

### Recall of Newton, Newton Fast, Newton Easyfit Harnesses – European Versions

Recall of certain batches of the European Version of NEWTON harnesses manufactured in 2022 (references C073AA01 C073AA02), NEWTON FAST (references C073CA01 and C073CA02) and NEWTON EASYFIT (references C073EA00, C073EA01, and C073EA02) due to a nonconforming batch of FAST LT buckles that could lead to a fatal fall. Immediately stop using the harnesses affected by this recall.



NEWTON  
european version



NEWTON FAST  
european version



NEWTON EASYFIT  
european version

### Identified Risk

We have identified a nonconforming batch of FAST LT buckles (see image of the buckles). On the affected harnesses, the FAST LT buckle is positioned at the chest and is used to fasten the harness.

If the harness is attached via the dorsal point and the FAST LT buckle breaks, the harness becomes unfastened. In the event that the user falls or is suspended in the harness, it is possible for them to completely exit the harness and fall to the ground.



FAST LT Buckles

### Immediate Action

If the harness is affected by the recall, immediately follow these instructions:

- Cease all use of the affected harnesses
- Quarantine these harnesses and return them to your supplier
- Distribute this information to your network

### FAQ's

Has this risk caused personal injury?

- No, not to our knowledge.

I have a European Version of the NEWTON harness, but the serial number is not included in the list of affected harnesses. Am I affected by this recall?

- No, only harnesses with the serial numbers included in the list are affected by this recall.



**ALWAYS**  
WEAR THE  
CORRECT PPE



**NEVER**  
EXPOSE YOURSELF  
TO A FALL AT WORK



## Product Recall – page 2 of 2

### Which harnesses are affected by this recall?

Only certain batches of the European Version of NEWTON harnesses manufactured in 2022 are affected by this recall. The European Version of the NEWTON harness range is not sold in the United States or Canada.

#### 1. Identify the reference on the harness

PRODUCT	REFERENCE
NEWTON European Version	C073AA01 C073AA02
NEWTON FAST European Version	C073CA01 C073CA02
NEWTON EASYFIT European Version	C073EA00 C073EA01 C073EA02

**Kits:** This recall also affects NEWTON harnesses (C073AA01/C073AA02) included in the ASAP FALL ARREST KIT (K093AB00/01/02/03) and ASAP LOCK FALL ARREST KIT (K094AA00/01/02/03).

#### 2. Identify the date of manufacture of the harness.



- If the harness **was not manufactured in 2022**, it is not affected by this recall.
- If the product **was manufactured in 2022**: The list of harness batches affected by this recall can be found [here](#).

## Immediate Action

**Can I inspect the buckles myself to determine whether they are non-conforming?**

- No because the nonconformity cannot be detected via visual inspection.

**Where do I find the reference and serial number?**

